
Meridian 1

Cabling guide

Document Number: 553-3001-109

Document Release: Standard 5.00

Date: October 1997

© 1994, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

December 1994

Standard, release 1.0. Initial release.

April 1995

Standard, release 2.0. Reissued to include editorial changes and indexing. Due to the extent of the changes, revision bars are not used.

July 1995

Standard, release 3.00. Reissued to include option 81C information, updated indexing and minor text and graphic edits. Revision bars are used to indicate changes.

December 1995

Standard, release 4.00. Reissued to include minor edits.

October 1997

Standard, release 5.00.

Contents

About this document	1
References	1
Introduction	3
Module cable routing	5
System configurations	9
System types	9
Engineering rules	10
Systems	11
Option 21, 21A, 21E	11
Options 51, 51C, 61, and 61C	13
Option 71	18
Option 81	22
Option 81C	24
Intra-module cabling	27
I/O panels	27
Universal I/O panel	28
Meridian 1 modules	30
CPU module	30
Network module	30
Intelligent peripheral equipment module	31
Peripheral equipment module	33
Remote peripheral equipment module	33

Common/peripheral equipment module	36
Core and Core/Network modules	36
Meridian Mail module	39
Application equipment module	40
Meridian Link module	40
Inter-module internal cabling	43
CPU to CPU	43
Network to network	44
CPU to network	44
Half-group network	44
Full-group network	47
CPU to network	47
Core module to core module	49
Core/Network Module to Core/Network Module	51
Network to PE	53
System monitor cabling	55
Inter-module external cabling	59
Network to Meridian Mail cabling	65
Module to external equipment cabling	67
System upgrade to Meridian 1	69
Upgrade to option 81C	69
Upgrade from SL-1 to Meridian 1 system	73
Upgrade from an SL-1 NT or XT	73
Upgrade from an SL-1 ST or RT	75
Appendix A: Internal and External Signaling Cables	79
A0660711 25DB Adapter Cable	79
QCAD309 Cable	79
QCAD328 DCHI Interface Cable	79

NT1R03 Shielded 4 Port with Ethernet Cable	79
NT1R03 Shielded 4 Port Cable	80
NT1R03 Shielded LAM Extension Cable	80
NT1R03 25DB M/M Extension Cable	80
NT1R03 25DB M/F Extension Cable	80
NT1R03 Max to IPE Modem Cable	80
NT1R04 Clock Controller to I/O Panel Cable	80
NT1R05 Intercabinet Module Cable	81
NT4R20 RSM Adapter Cable	81
NT5D19AA Maintenance Cable	81
NT5D50AA DBX Ribbon Cable	81
NT6D4405 CRT Cable	81
NT6D4406 RSM Cable	81
NT6D4407 GSP Cable	81
NT6D4408 NVP Cable	81
NT6D4410 CSL Cable	82
NT6D4411 DVS Bus Node to Node Cable	82
NT6D4412 DVS Bus Internal Cable	82
NT6D4413 DVS Bus ESBC Terminator	82
NT6D4414 DVS Bus Node 1 to 2 Cable	82
NT6D4415 DVS Bus HABC Terminator	82
NT6D4416 DVS Bus, Node 2 to 3 Cable	82
NT6D54 QBL15 Field Wiring Kit (DC)	82
NT6P0110 Four-Port Cable	83
NT7D61Ex SDI I/O Cable	83
NT7D89 RS-232 to I/O Panel Cable	83
NT7D90 Ethernet to I/O Panel Cable	83
NT7D94 VME Transceiver Cable	83
NT7D95 VME Transition Cable	83
NT8D46AA System Monitor Stack Cable	84

NT8D46AB System Monitor Jumper Cable	84
NT8D46AD System Monitor Quad Serial Data Interface Cable	84
NT8D46AF System Monitor Remote Serial Data Interface Cable	84
NT8D46AG System Monitor to Extended Serial Data Interface Cable	84
NT8D46AJ UPS Alarm Cable (AC)	84
NT8D46AK UPS Alarm Cable (AC)	84
NT8D46AL System Monitor Serial Link Cable	85
NT8D46AN XDF to PFT Cable	85
NT8D46AP System Monitor Serial Link Cable	85
NT8D46AQ UPS Alarm Cable (AC)	85
NT8D46AS System Monitor Inter-CPU Cable	85
NT8D46AT System Monitor/QBL15 Cable (DC)	85
NT8D46AU UPS Alarm Cable (AC)	85
NT8D46AV System Monitor/QCA13 Cable (DC)	85
NT8D46AW System Monitor/QBL12 Cable (DC)	86
NT8D46AX System Monitor CE/PE ST Upgrade Cable	86
NT8D46AY System Monitor XPE ST Upgrade Cable	86
NT8D46BA ST Upgrade QCA136 Internal Cable	86
NT8D46BB ST Upgrade QCA136 Internal Cable with Expansion	86
NT8D46BC ST Upgrade QCA137 External Cable	86
NT8D46BD ST Upgrade QCA136 External Adapter Cable	86
NT8D46BE ST Upgrade QCA136 External Cable	86
NT8D46BF ST/RT Upgrade System Monitor External Adapter Cable	87
NT8D46BG RT Upgrade QCA147 Internal Cable	87
NT8D46BH System Monitor to MDF Cable	87
NT8D46BJ Upgrade QCA147 Internal Cable with Expansion	87
NT8D46BK RT Upgrade QCA137 External Cable with Expansion	87
NT8D46BL RT Upgrade QCA147 w/Expnsn Ext. Adapter Cable	87
NT8D46BM ST Upgrade QCA136 w/Expnsn Ext. Adapter Cable	87
NT8D46CA System Monitor Stack Cable for 2MB RPE	88

NT8D46CB System Monitor to AEM Cable	88
NT8D46CC System Monitor Jumper Cable	88
NT8D46CD System Monitor to AEM Cable	88
NT8D46CH RT Upgrade QCA147 External Cable	88
NT8D46DH/EH System Monitor to MDF Cable	88
NT8D46FH System Monitor to SL-100 Cable	88
NT8D6802 MSI-FDU Cable	88
NT8D7205 PRI to I/O Panel Cable	89
NT8D7208 PRI 2 to I/O Panel Cable	89
NT8D7209 PRI 2 to MDF Cable	89
NT8D7210 PRI 2 to I/O Panel Cable	89
NT8D73 Network I/O to Network I/O Intercabinet Cable	89
NT8D74 Clock Controller to Junctor Cable	89
NT8D75 Clock Controller to Clock Controller Cable	90
NT8D76 InterGroup Switch to Junctor Cable	90
NT8D77 Floppy Disk Interface to Floppy Drive Unit Cable	90
NT8D78 CPU Cable	90
NT8D79 DTI to Clock Controller Cable	91
NT8D80 CPU Interface Cable	91
NT8D81 B/P Tip and Ring to I/O Cable	91
NT8D82 SDI to I/O Cable	91
NT8D83 DTI to I/O Cable	92
NT8D84 XSDI to I/O Cable	92
NT8D85 Network to PE Cable	92
NT8D86 Network to I/O Cable	92
NT8D87 XCT to Music Trunk Cable	92
NT8D88 Superloop Network Card to I/O Cable	93
NT8D89 I/O Panel to Echo Canceler Cable	93
NT8D90 SDI Multiple Port Extension Cable	93
NT8D91 Superloop Network to Peripheral Controller Cable	93

NT8D92 I/O to Peripheral Controller Cable	93
NT8D93 XSDI I/O to DTE or DCE Cable	93
NT8D95 SDI I/O Panel to DTE or DCE Cable	94
NT8D96 SDI Multiple Port Cable	94
NT8D97 DTI I/O Panel to MDF Cable	94
NT8D98 Superloop Network I/O to Superloop Network I/O Intercabinet Network Cable	94
NT8D99 CPU to Network Cable	94
NT9J93 DTI Echo Canceler to I/O Cable	94
NT9J94 RPE to I/O Cable	95
NT9J95 Peripheral Controller Maintenance Cable	95
NT9J96 Network to I/O Intracabinet Network Cable	95
NT9J97 Superloop Network to I/O Intracabinet Network Cable	95
NT9J98 Network to ST I/O Intracabinet Network Cable	95
NT9J99 Superloop Network to ST I/O Intracabinet Network Cable ..	96
NTAK0410 Battery Cable	96
NTBK04 1.5MB DTI/PRI T1 Cable	96
NTBK04 1.5MB Carrier/Clock Cable	96
NTBK04 1.5MB DTI/PRI Carrier Cable	96
NTBK04 1.5MB DTI/PRI Carrier Cable	96
NTBK05 SDT12 120-OHM E1 Cable	96
NTBK05 2MB DTI/PRI Coax Carrier Cable	96
NTND11 CMB to CMB Cable	97
NTND13 SCSI Cable	97
NTND14 CNI to 3PE Cable	97
NTND26 MDSL to DCHI Cable	97
NTND27 MSDL to I/O Panel Cable	97
NTND27 MSDL SDI/AM2 Cable	98
NTND28 Network Expansion Intercabinet Cable	98
NTND29 Network Expansion CPU Interface Cable	98

NTND30 Network Expansion Junctor to I/O Housing Cable	98
NTND37 Dual SDI Cable	98
NTND71 BRA Clock Reference to Clock Controller Cable	98
NTND72 Clock Reference to Clock Controller Cable	98
NTND80 MSI to CMDU Upgrade Cable	99
NTND82 Printer to LIU Cable	99
NTND91 CSL Cable	99
NTND91 Extension-25DB Cable	99
NTND94 CNI to I/O Panel Cable	99
NTND94 Cable	99
NTND95 EMI Box to 3PE Cable	99
NTND98 PRI to I/O Panel Cable	100
Appendix B: Cabling assignment tables	101
Appendix C: Cross-reference listing	173

